




## NOTES

1. Internal connecting wire (1/3.5-gage) to be installed across width of interior Gables and across width and length of end Gables.
2. Internal connecting wire and Gable mesh shall be galvanized.
3. Internal connecting wires required on all gables 1 m high.
4. Preformed stiffeners (1/2-gage or 9-gage) are an acceptable alternative to internal connecting wires. Install them as recommended by manufacturer or as directed by the Engineer at 1/3 points.
5. Place rock in end Gable cell first, and continue by filling interior Gable cells.
6. For Gable dimensions, refer to table "Standard Gable Sizes".



STATE OF CALIFORNIA  
DEPARTMENT OF TRANSPORTATION

**GABION BASKET DETAILS No. 1**

NO SCALE

ALL DIMENSIONS ARE IN  
MILLIMETERS UNLESS OTHERWISE SHOWN

**D100A**